


Note:

Transmission at operating temperature.
Transmission oil,
refer to BMW Service Operating Fluids
Fill quantity,
refer to Technical Data



Unfasten drain plug (1) and filler screw (2).
Clean drain plug and screw in.
Tightening torque,
refer to Technical Data 23 00 4AZ
Top up transmission fluid until it overflows.
Tighten in filler screw (2).
Tightening torque,
refer to Technical Data 23 00 4AZ