

35 00 Rear Axle in General E36

Spacing between accelerator pedal and Brake pedal Measuring points, see Rep. Manual		
Manual transmission J	mm	50
Autom. transmission K	mm	60
Distance tunnel-brake pedal Measuring points, see Rep. Manual		
Manual transmission F	mm	135 ± 5
Automatic transmission G	mm	145 ± 5
Spacing H between brake pedal and Clutch pedal Measuring points, see Rep. Manual	mm	50
Specified distances are reference values only and do not account for installation tolerances. Distances without consideration for carpets.		