

Remove rear wheel,
refer to 36 10 300.

Unfasten screws (1) and nuts (2).
Lever out and remove wheel arch trim (3).

