

11 23 Vibration Damper

	Type	Thread	Tightening specification	Measure	
2AZ Vibration damper / hub to crankshaft	S38 B36	M20 x 1.5	Replace screw	150 Nm	
			Jointing torque		
			Unfasten screw one half turn		
			Jointing torque		60 Nm
			Torque angle		60 °
			Torque angle		60 °
	S38 B 38	M12 x 1.5	Replace screws	60 Nm	
			Jointing torque		50 °
			Torque angle		50 °
S50 / S62 / S54	M12 x 1.5	Replace screws	60 Nm		
		Jointing torque		50 °	
		Torque angle		50 °	