
35 41 480 Replacing kickdown switch (EH transmission)




Testing - see Status List Diagnosing Program 03 EGS and use BMW SERVICE TESTER or MODIC.

Pull off flat male connector (1).

Unscrew nut (2).

Unscrew switch.



Installation:

Adjust nut to control distance C, see Technical Data.

Make final adjustment after installation.