



T Bush of rear axle mount

W Rear spring support (spring seat)

U Supports for shock absorber

V Impact absorber support, rear

Dimensions in mm

Tolerance: dimension over 1000 mm  $\pm$  2.0 mm

Tolerance: dimension up to 1000 mm  $\pm$  1.0 mm

Note:

Only use the indicated values for a rough inspection.

Repairs can only be carried out correctly with the approved set of attachments and with straightening bench.