

Raise hood lid.


Remove inside wheel housing cover.

Remove turn indicator side repeater,  
refer to 63 12 200


Unscrew screw.

1 = Side wall, front

2 = Trim for cover on side member



Open door and unfasten screw.



Unscrew upper mounting bolts.

Remove front side panel.

