## Replacing mirror glass for rear-view mirror (on front door)

## Caution!


Make sure car has room temperature to prevent the clips from breaking off.

Tilt mirror glass.

Remove cement between mirror glass and edge of housing (risk of damage).

36 51 005

Unclip mirror glass using a wooden wedge. If applicable, remove connector (mirror glass heating) and remove mirror glass.



## Installation:

Install mirror glass that clips are seated on tabs and clip on glass.

Ensure correct engagement.

Check function.

## 1111 36 51 006