

Remove door trim panel,
refer to 51 41 000

Unfasten screw, unclip door handle from linkage and remove.

