



Remove mocket from front roof column (A-column
finisher).

Pull trim (1) inwards to unclip; then pull obliquely upwards to
remove.

**Installation:**

If necessary, replace damaged clips.