Removing and installing / replacing right trunk wheel housing trim (Z3 Roadster, M Roadster)


Removing and installing socket housing for right tail light,

refer to 63 21 055

Remove floor mat.

M Rodaster:


Remove M-Mobility System if necessary, refer to Owner's manual.



Version without battery in the luggage compartment: Unfasten clip (1) and remove trunk wheel housing trim (2).


Installation:

Guide trunk wheel housing trim (2) into the rear apron trim (3) at the bottom.



Version with battery in the luggage compartment (except M Roadster):

Unfasten nut (1) and take out tray (2).



Version with battery in luggage compartment: Unfasten clips (1) and remove trunk wheel housing trim (2).

Installation:

Guide trunk wheel housing trim (2) into the rear apron trim (3) at the bottom.