

54 21 060 Removing and installing/replacing mounting plate, front left or right

Remove hard top, refer to 54 21 001.

Detach cover (1) on mounting plate towards front.





Release screws (2) and remove mounting plate.

1 Cowl panel